

INSTRUCTIONS

Standard – Preset sharpening angles for most straight edge pocket knives and sporting/outdoor knives.

Utility – Preset sharpening angles for utility knives.

Sharpening Instructions:

1. Place sharpener on a flat surface and hold as shown. (Fig. 1) **Keep fingers behind the finger guard or injury could occur.**
2. Insert blade fully into slot.
3. Apply moderate downward pressure and pull through slot from heel to tip. Sharpen all the way out to the tip. (Fig. 2)
4. Repeat this action until sharp.

NOTE: Normally it takes 3-4 strokes to reset a sharp edge. Blades made of harder steels may require additional strokes.

Standard – Angles d'affûtage prééglés pour la plupart des couteaux à lame droite et des couteaux de sport/d'extérieur.

Cutter – Angles d'affûtage prééglés pour les cutters

Instructions d'affûtage:

1. Posez l'affûteur sur une surface plane et tenez-le comme illustré. (Fig. 1)

Assurez-vous que vos doigts se situent derrière le protège doigts, sans quoi vous pourriez être blessé.

2. Insérez complètement la lame dans la fente.

3. Appuyez en appliquant une pression modérée et tirez la lame avec un mouvement allant du talon vers la pointe pour aiguiser tout le tranchant de la lame. (Fig. 2)

4. Recommencez jusqu'à ce que la lame soit tranchante.

REMARQUE: Normalement, 3-4 passages sont requis pour l'obtention d'une lame tranchante, mais les lames faites d'un acier plus dur peuvent nécessiter des passages supplémentaires.

